


# Wurlitzer 1700




**Parts Catalog specific to W 1700**




Selector Switch Assembly (Part 1)






Selector Switch Assembly (Part 2)




*Top Support Casting Assembly*






*Turntable Motor and Gear and Shaft Assembly*




*Tone Arm Assembly*




*Turntable Shaft Assembly, Record Clamp Shaft, and Mounting Plate and Ball Bearing Assembly*






*Record Guide Assembly*






*Record Carrier Assembly*




*Chassis Mounting Plate and Pivot Casting and Arm Assembly*






*Chassis Frame Casting and Shaft Assembly*




*Selector Shaft Assembly and Main Cam and Bushing Assembly*






*Electric Selector and Junction Box Assembly*



Cabinet Assembly and Trim - Front





*Dome Assembly*